ReiseHaarTrockner RHT 02

petra electric

D **Gebrauchsanweisung**

GB **Instructions for use**

(D) Gebrauchsanweisung

petra® electric

Vor dem Benutzen

Die Gebrauchsanweisung aufmerksam lesen. Sie enthält wichtige Hinweise für den Gebrauch, die Sicherheit und die Wartung des Gerätes. Sie soll sorgfältig aufbewahrt und gegebenenfalls an Nachbenutzer weitergegeben werden. Das Gerät darf nur für den vorgesehenen Zweck, gemäß dieser Gebrauchsanweisung, verwendet werden. Beim Gebrauch die Sicherheitshinweise beachten.

Sicherheitshinweise

Achtung! Dieses Gerät nicht in der Nähe von Badewannen, Waschbecken oder anderen Gefäßen, die Wasser enthalten, benutzen oder ablegen. Gefahr besteht auch bei ausgeschaltetem Gerät. Deshalb stets den Netzstecker ziehen, wenn der Haartrockner nicht benutzt wird.

Der Einbau einer Fehlerstromschutzeinrichtung mit einem Nennauslösestrom von nicht mehr als 30 mA in der Hausinstallation bietet zusätzlichen Schutz. Wenden Sie sich an Ihren Elektroinstallateur.

⚠ Dieses Gerät ist nicht dafür bestimmt, durch Personen (einschließlich Kinder) mit eingeschränkten physischen, sensorischen oder geistigen Fähigkeiten oder mangels Erfahrung und/oder mangels Wissen benutzt zu werden, es sei denn, sie werden durch eine für ihre Sicherheit zuständige Person beaufsichtigt oder erhielten von ihr Anweisungen, wie das Gerät zu benutzen ist.

⚠ Achten Sie darauf, dass Kinder keine Gelegenheit erhalten, mit dem Gerät zu spielen.

⚠ Gerät nur an Wechselstrom - mit Spannung gemäß Typschild - an eine vorschriftsmäßig installierte Steckdose anschließen. Zuleitung und Stecker müssen trocken sein.

⚠ Den Netzstecker nicht an der Leitung oder mit nassen Händen aus der Steckdose ziehen.

⚠ Die Zuleitung vor der heißen Luft schützen.

⚠ Die austretende Luft kann sehr heiß werden. Deshalb das Haar immer in ausreichendem Abstand behandeln, da ansonsten Verbrennungsgefahr besteht. Die Frisierdüse vor dem Abnehmen immer erst abkühlen lassen.

⚠ Gerät nicht an nassen Haaren oder an Kunststoffhaaren anwenden. Vor der Anwendung Haare frottieren.

⚠ Die Luftansaugöffnung nicht durch Kleidung, Haare oder Hände abdecken.

⚠ Das Gerät auch zum kurzzeitigen Ablegen ausschalten.

⚠ Das Gerät nicht in Betrieb nehmen bzw. sofort Netzstecker ziehen, wenn:

- Gerät oder Netzkabel beschädigt ist
- der Verdacht auf einen Defekt nach einem Sturz oder Ähnlichem besteht.

In diesen Fällen das Gerät zur Reparatur geben.

⚠ Zum Aufbewahren des Gerätes die Zuleitung nicht knicken und nicht straff um das Gerät wickeln.

⚠ Bei Zweckentfremdung, falscher Bedienung oder nicht fachgerechter Reparatur wird keine Haftung für eventuelle Schäden übernommen. Ebenso sind Garantieleistungen in solchen Fällen ausgeschlossen.

⚠ Das Gerät ist nicht für den gewerblichen Gebrauch bestimmt.

⚠ Wenn die Anschlussleitung dieses Gerätes beschädigt wird, muss sie durch den zentralen Kundendienst des Herstellers oder eine ähnlich qualifizierte Person ersetzt werden. Durch unsachgemäße Reparaturen könnten erhebliche Gefahren für den Benutzer entstehen.

Spannungsumschaltung

Das Gerät kann bei Netzspannung 120 V oder 230 V betrieben werden. Seitlich am Griff befindet sich der Umschalter.

⚠ Vor dem Anschließen des Netzsteckers muss kontrolliert werden, ob die richtige Netzspannung eingestellt ist.

Bei Bedarf den Schalter mittels einer Münze umstellen.

Inbetriebnahme

Zuerst den Griff aufklappen, bis er einrastet.

Mit dem Schalter kann die Heiz- und Luftleistung individuell angepasst werden.

Stufe 0	Gerät ausgeschaltet
Stufe 1	Heizung 600 W / normaler Luftstrom
Stufe 2	Heizung 1200 W / starker Luftstrom

Werden die Lufteintrittsöffnungen abgedeckt oder sind sie mit Haaren zugesetzt, wird die austretende Luft zu heiß, und der Überhitzungsschutz schaltet das Gerät ab. Sollte dieser Fall einmal eintreten, den Schalter auf -**0**- stellen. Nach ca. 5 Minuten ist der Haartrockner wieder betriebsbereit. Zuvor bei Bedarf das Gerät bei gezogenem Netzstecker reinigen.

Richtdüse

Mit der vorn aufgesteckten, drehbaren Richtdüse können einzelne Haarpartien wie z. B. mit Lockenwicklern oder Rundbürste gezielt getrocknet werden.

Reinigung und Pflege

Vor jeder Reinigung den Netzstecker ziehen.
Nach Benutzung das abgekühlte Gerät von Haaren befreien.
Das Gerät keinesfalls in Wasser tauchen, nur mit einem feuchten Tuch abwischen und trockenreiben.

Garantie-Information

Für unsere Geräte übernehmen wir gegenüber dem Endkunden eine 24-monatige Haltbarkeitsgarantie. Sie beginnt mit dem Kauf des Gerätes durch den Endkunden und gilt im Gebiet der Bundesrepublik Deutschland.
Ansprüche aus dieser Garantie sind unter Vorlage des Kaufbelegs direkt gegenüber unserem zentralen Kundendienst geltend zu machen.
Von der Garantie ausgeschlossen sind Schäden durch normalen Verschleiß, unsachgemäßen Gebrauch sowie unterbliebene Pflege.
Der Endkunde besitzt zusätzlich zu den Ansprüchen aus dieser Garantie gesetzliche Ansprüche wegen Mängeln des Gerätes gegenüber seinem direkten Verkäufer/Händler, die durch diese Garantie nicht eingeschränkt werden.

petra - electric
Kundendienst
Greisbacherstraße 6
D - 89331 Burgau

www.petra-electric.de

CE Das Gerät entspricht den Europäischen Richtlinien 2006/95/EG und 2004/108/EG.

Dieses Produkt darf am Ende seiner Lebensdauer nicht über den normalen Haushaltsabfall entsorgt werden, sondern muss an einem Sammelpunkt für das Recycling von elektrischen und elektronischen Geräten abgegeben werden.
Die Werkstoffe sind gemäß ihrer Kennzeichnung wiederverwertbar.
Mit der Wiederverwendung, der stofflichen Verwertung oder anderen Formen der Verwertung von Altgeräten leisten Sie einen wichtigen Beitrag zum Schutze unserer Umwelt.
Bitte erfragen Sie bei der Gemeindeverwaltung die zuständige Entsorgungsstelle.

Änderungen vorbehalten.

Before using

Read the instructions carefully. They contain important notes for the use, safety and maintenance of the appliance. Keep them in a safe place and transfer them to a possible succeeding user. Only use the appliance for the purpose mentioned in these instructions. When using pay particular attention to the following safety advice.

Safety advice

Attention! Never use or store this appliance near bath tubs, wash-basins or other receptacles containing water. This safety advice is also valid when the appliance is switched off. Always disconnect the appliance if not in use. An additional protection is offered by an indoor installation of a safety device against voltage irregularities with a trigger mechanism of not more than 30 mA.

Please refer to your professional electrician.

⚠ This appliance is not meant to be used by persons (including children) with reduced physical, sensorial or mental capacities or in absence of the necessary experience and/or knowledge - unless they are supervised by a person responsible for their safety and from whom they get instructions on how to use the appliance.

⚠ Keep out of reach from children.

⚠ Only connect the appliance to alternating current - with a rating voltage according to the rating plate – to a correctly installed earthed socket. Cord and plug must be dry.

⚠ Do not pull out the plug by the cord or touch it with wet hands.

⚠ Protect the cord from hot air.

⚠ The escaping air can become hot. Therefore keep hair at a distance from the dryer in order to avoid scalding.

Also always let the styling nozzle cool down before taking it off.

⚠ Do not bring the appliance in contact with wet hair or artificial hair. Before use, towel down your hair.

⚠ Do not cover the air intake opening with clothes, hair or hands.

⚠ Always switch off the appliance before putting it down.

⚠ If the following happens do not use the appliance and unplug it immediately:

- the appliance or the mains cable is damaged
- any defect after the appliance has accidentally dropped or something similar is suspected.

In these cases have the appliance repaired.

⚠ For storing the appliance do not fold the cord and do not tightly wrap it around the appliance.

⚠ In the case of misuse, wrong handling or incorrect repair no liability will be taken for possible damages. Claims under guarantee are also excluded in such cases.

⚠ The appliance is not designed for commercial purposes.

⚠ In case the cord of this appliance is damaged, it must be replaced by the manufacturer's authorised service agent or a qualified person. Substantial dangers for the user can result from inappropriate repairs.

Choice of Voltage

The appliance can be operated with a nominal voltage of 120 V or 230 V. The switch for selecting the voltage is located on the side of the handle.

⚠ Please check carefully the voltage before plugging the appliance to the socket.

If you have to change the voltage use a coin to turn the switch.

Putting into operation

First click the handle into place.

The switch is used to adjust the heat and air settings individually:

setting 0	appliance is switched off
setting 1	heating 600 W / normal air fan
setting 2	heating 1200 W / strong air fan

When the air outlets are covered or when they are blocked with hair the outcoming air is getting too hot and the overheating protection switches off the appliance. In this case put the switch on position -**0**-.

After about 5 minutes the hairdryer can be put into operation again. Before, - if necessary - clean the appliance when unplugged.

Styling nozzle

The attachable and turnable styling

nozzle is used to dry individual hair parts, for example hair put in curlers or when using a round brush.

Cleaning and maintenance

Before cleaning always unplug the appliance. After using clean the appliance - which has cooled down - from hair.

Never immerse the appliance in water, only clean it with a damp cloth and rub dry.

petra - electric
Kundendienst
Greisbacherstraße 6
D - 89331 Burgau

www.petra-electric.de

For UK use only

1. This product is supplied with a 13 A plug conforming to BS 1363 fitted to the mains lead. If the plug is unsuitable for your socket outlets or needs to be replaced, please note the following. If the plug is a non-rewireable one, cut it from the mains lead and immediately dispose of it. Never insert it into a socket outlet as there is a very great risk of an electric shock.
2. The replacement of the plug at the mains lead has to be done according to the following instructions:
   Important: The wires in this mains lead are coloured in accordance with the following code:
   blue: Neutral
   brown: Live
   As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:
   - the wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black,
   - the wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

   Do not connect any wire to the terminal which is marked with the letter E or by the earth symbol ⏚, or coloured green or green and yellow.
3. If a 13 A (BS 1363) plug is used it must be fitted with a 13 A fuse conforming to BS 1362 and be ASTA approved. If any other type of plug is used, the appliance must be proctected by a 10 A fuse either in the plug or adapter or at the distribution board.
   If in doubt - consult a qualified electrician.
4. Never use the plug without closing the fuse cover.

CE The appliance complies with the European directives 2006/95/EC and 2004/108/EC.

At the end of its lifetime this product must not be disposed of through the normal domestic waste, but it should be handed to an assembly point for the recycling of electrical and electronical appliances. You can inquire about details at the local administration.

Subject to changes.

petra®
electric

petra - electric
Kundendienst
Greisbacherstraße 6
89331 Burgau

www.petra-electric.de

Änderungen vorbehalten - 081222